





GoPro MAX Replacement Door

248847

Replace your original MAX door if it's damaged or lost. Easily snap this door into place to maintain the camera's waterproof rating and keep debris out of the USB-C port, battery compartment and SD card slot.

Style MAX

PRODUCT DETAILS

Replace your original MAX door if it's damaged or lost. Easily snap this door into place to maintain the camera's waterproof rating and keep debris out of the USB-C port, battery compartment and SD card slot.

Features

- · Replacement door for MAX
- · Easily snaps into place
- Maintains the camera's 16ft (5m) waterproof rating and keeps debris out of the USB-C port, battery compartment and SD card slot

Specs

Product Attributes

EAN: 0818279023916

Manufacturer number: ACIOD-001

Product weight: 0.01 kilograms

Pieces per master carton: 1 Piece

Technical Specifications

Compatible models: MAX