



polaroid

600 Color Film Color Frames 8x

250908

The original format instant film for your vintage camera. Each pack has a small battery to power the Polaroid 600 cameras from the '80s and beyond, but it works with our i-Type cameras too. A timeless formula to create captivating moments you can relive and retell forever.

PRODUCT DETAILS

Stijl	BLACK&WHITE, COLOR FILM COLOR FRAMES, COLOR FILM, COLOR FILM ROUND FRAME
Grootte	8X , 2X8, 3X8, 40X

Polaroid 600 Color Film Color Frames Edition

Just like the camera it goes with, 600 film is straightforward and easy to use. It also comes in a variety of special editions, like this Colored Frame Edition. With it, you get the same rich, textured photos as classic 600 film, but each photo is framed in a different color – red, green, purple, and more. It's great for parties and kids' events, and you never know which color you're going to get next. Well, there's a secret, of course, but why spoil the fun?

- 8 Instant Photos
- Format: 3.5" × 4.25" (8.8 cm × 10.8 cm)
- 8 different colored frames
- ASA 640
- Photos develop in 10–15 mins
- Best stored refrigerated

Store chilled, shoot warm

Temperature affects how the film works. Keep it stored cold in the fridge, but never freeze it. Ideally you should let it adjust to room temperature before you use it. That's around 55–82°F (13–28°C). When it's cold out, keep your photos warm in a pocket close to your body while they develop. Or if it's a hot day, make sure they stay cool.

Shoot with the light

The more light in your shot, the better your photo will turn out. Instant film loves light, especially natural light. Use the flash for all your indoor photos. For best results we also recommend using the flash for outdoor shots, unless it's a bright sunny day.

Develop in the dark

All photos appear blank at first. They're most sensitive during this time, so don't bend or shake them. Shield them from the light, and place them face down as they develop. Keep B&W photos shielded from light for about 1 minute, and color film for about 6 minutes.

Care for your camera

Your camera has a set of rollers inside the film door. Each photo passes through these rollers as it's made, so it's important to make sure that they stay clean. If the rollers get visibly dirty then gently wipe them down with a soft, damp cloth.

For use with:

- Polaroid Impulse
- Polaroid 600
- Polaroid SLR680
- Polaroid i-Type
- Impossible i-Type
- Impossible Instant Lab

Specificaties

Product attributen

EAN:	9120096770784
Fabrieksnummer:	006015
Productgewicht:	0.09 kilograms